



Low Profile 4-Zone Speaker Selector

AS-SS4

SKU: 65731 UPC: 8642932441

Low Profile 4 Zone Speaker Selector

Feature

- Route speaker cables from each listening zone to the speaker selector
- Route speaker cables from the amplifier to the speaker selector
- Remove approximately 8 inches of the outer jacket from the speaker cable (if necessary)
- Strip approximately 3/8 inches of insulation from each conductor and twist the exposed strands together to avoid fraying
- Press the push terminal and insert the conductor; release to make contact
- Set Impedance Protection to ON and OFF as necessary